



2/43 Industrial Avenue, Hoppers Crossing, VIC, 3029. Email: admin@melbournemouldedauto.com.au

Moulded Car Carpet Fitting Instructions

1. Remove door sill plates, kick panels, front and rear seat bases, consoles, seat belt bolts and any other items fixed to the existing carpet.
2. Remove old carpet and retain for step 5.
3. Remove old underfelt making a note of its position in the vehicle.
4. Clean the area in preparation for fitting the new carpet.
5. Place the old carpet over the new carpet to form a template and mark holes and cut outs with chalk (do not cut at this point).
6. Install new underlay or replace original underlay in the same position the underlay was removed from the vehicle.
7. Starting from the rear, place your new moulded carpet in the vehicle centring it on the tunnel and working towards the sides.
8. Repeat step 7 for the front carpet.
9. Push the front carpet forwards to tighten the carpet over the tunnel/hump, the top of the carpet may need to be trimmed to fit. Ensure you match the contours of the carpet with the floor to confirm the correct fit, there should be an overlap of approximately 50mm of front carpet over the rear piece. You may need to cut the holes marked in step 5. Start with a x cut, then enlarge gradually if required.
10. Depending on your vehicle model, trim sides of carpet (excess is given to allow for adjustment in the fitting process).
11. Replace all trims and fixtures removed in step 1.

For fitting **Left & Right Carpets** – follow the instructions above however replace installing Front & Rear with Left & Right.

For fitting **Backwalls & B Pillars** – install the Backwall first followed with the B Pillars using a contact adhesive glue (test glue on patch first).

Congratulations! Enjoy your new carpet!

*Please note – These instructions are generic, to be used as a guide only. For assistance with fitting please consult with your local motor trimmer.